

2:1 TO 1:1 CONVERSION

The Omega kite can be switched from a 2:1 bridle configuration to a 1:1 bridle configuration. The 2:1 configuration is for use with a 2:1 [pulley] equipped control system. The 1:1 configuration is for use with a 1:1 [no pulley] control system. It is recommended that this conversion be done with the kite inflated. (Fig 1). NOTE: To complete the conversion, you must also convert your control system. See the Powerdrive 2N1 User Manual for instructions.

2:1 TO 1:1 CONVERSION

- 1) Move the C-3 bridle from TP5 to TP4 (img 2)
- 2) Move the #6 bridle towards the kite one knot (img 3)

TUNING IN 1:1 MODE

Doing this modification will slightly over sheet the kite. When you reattach your rear lines to the rear pigtail, please use the lowest knot (Position 1).

